















Tide




PBJ
DESIGNHOUSE
1968







5




6




7




8




9









1



2



4

	Please tighten the screws/legs after 4-5 weeks of use and then subsequently every 4-5 months.
	We do not recommend that young children are present during assembly due to the risk of choking on small parts and/or injury. Never leave your child unattended with furniture that has not been fully assembled.
	Requires 2 persons to lift.
	Do not push or drag boxes or furniture across the floor - please lift when moving.
	We recommend using a non-slip rug underlay.
	This product is for indoor use only.
	Do not place the furniture in direct sunlight.
	Do not use furniture as a climbing aid.
	Do not sit, stand or jump on the table